

PRE-MONTAGGIO

1. Predisporre l' impianto idraulico come indicato in fig. 4.
2. Spurgare bene le tubazioni di alimentazione.
3. Fissare il MIX incasso (fig.1)
Verificare l' allineamento orizzontale (fig.4) e la posizione nel muro seguendo scupolosamente le istruzioni (fig. 2)
4. Predisporre l' allacciamento per la BOCCA di erogazione seguendo le indicazioni rispetto al muro finito (fig. 3) -13/+2mm

MONTAGGIO MIX

- Sfilare la calotta di protezione (X) (fig. 2/a)
Montare i particolari: A, B, (fig. 2/b)
Stringere il grano B1 con la chiave in dotazione e avvitare le leva (C) (fig. 2/b)

MONTAGGIO CANNA

- (fig. 3)
Avvitare a tenuta la spina (D) servendosi dell' apposita sede (D1).
Calzare la canna (E) sulla spina (D) interponendo la basetta (F) e stringere il grano (G) con la chiave in dotazione.

PRE-ASSEMBLY

1. Prepare plumbing connections as per fig.4
2. Flush through supply pipes.
3. Fix cartridge body as per fig.1
Check horizontal line (fig.4) and follow wall position indications (fig.2)
4. Prepare plumbing connection for the spout checking that the allowed position range (-13/+2mm) towards the finished wall is matched (fig.3)

MIXER ASSEMBLY

- Remove (unscrew) protection cap (X) (fig. 2/a)
Insert parts (A) and (B) (fig. 2/b)
Tighten grub screw (B1) with enclosed allen key and screw lever (C) onto handle (B) (fig. 2/b)

SPOUT ASSEMBLY

- (fig.3)
Tighten pin (D) by using (D1).
Insert spout (E) onto pin (D) after inserting ring (F). Tighten grub (G) with enclosed key.

